


FIG. 1






FIG. 3




FIG. 4




FIG. 7





FIG. 8






FIG. 10

FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15




FIG. 16




FIG. 17




FIG. 18




FIG. 19




FIG. 20




FIG. 21




FIG. 22




FIG. 23




FIG. 24

Analog Signal Conditioning Subsystem (101)




FIG. 25

Signal Processing Subsystem (102)




FIG. 26




FIG. 27

Software Program - Header Format (135)

Version Information: (152)

File version major File version minor

Patient Information: (154)

Patient name
Patient initials
Age
Weight
Sex
Height (Feet and Inches)
Birth date
Current date
Comments

Pad Information: (155)

Model name Vertical number of electrodes Horizontal number of electrodes Vertical electrode spacing (cm) Horizontal electrode spacing (cm)

Calibration Information: (156)

Spinous process T-10x coordinate (pixels) Spinous process T-10y coordinate (pixels) Left PSIS x coordinate (pixels) Left PSIS y coordinate (pixels) Right PSIS x coordinate (pixels) Right PSIS y coordinate (pixels)

Data Acquisition Settings: (157)

Number of channels scanned Pre-amplifier gain Analog digital board gain Scan rate (seconds) Scan period (seconds) Pre-scan period (milliseconds)

Display Settings: (158)

Minimum voltage to display (display software will show voltages below this value as saturated) Maximum voltage to display (display software will show voltages above this value as saturated)

FIG. 28

Software Program - File List

Analog-to-Digital (*A2D) Files (130)

A2D files contain the actual analog-to-digital values collected from the National Instruments hardware during a test. The files contain the header described above and the Analog-to-digital values. The structure of an A/D scan is:

```
<Scan 1, channel 1>< Scan 1, channel 1, channel 3>...
<Scan 2, channel 1>< Scan 2, channel 2, channel 3>...
```

Each scan is stored in a two byte word in little endian format.

```
Voltage (*.DAT) Files (132)
```

DAT files contain the voltage data from a test, after it has been converted from A/D values to voltages and signal conditioning filters have been applied. The files contain the header described above followed by the voltage values. The Format is:

```
<Scan 1, channel 1><Scan 1, channel 2><Scan 1, channel 3>...
<Scan 2, channel 1><Scan 2, channel 2><Scan 2, channel 3>...
etc...
```

Each scan is stored as an IEEE double floating point value.

```
RMS (*.RMS) Files (134)
```

RMS files contain the RMS values of the differences between the voltage waveforms of adjacent electrodes. During display of an RMS file, the values can then be mapped to colors, and displayed as colored line segments. The files contain the header described above by the RMS information.

The RMS voltage differences is calculated for each pair of adjacent electrodes. The row and column position of each of the two electrodes are also stored.

First electrodes' row number First electrodes' column number Second electrodes' row number Second electrodes' column number RMS values

The following information about the RMS values is also stored:

Minimum RMS value in scan Maximum RMS value in scan Total number of adjacent electrodes pairs

FIG. 29

Software Program Source File Structure (160)

Document/view and visual interface:

PDIMFC.CPP MAINFORM.CPP CHILDFORM.CPP Main initialization of application, display of splash screen and about dialog box.

Message handlers for main window, menu and toolbar commands

Message handlers for child windows (the views).

PDNIFCDOC.CPP Document: handles the commands to create new RMS files open existing ones. **GRAPH.CPP** Document: reads RMS files and calculates the colors to display for RMS values. PDINFCVIEW.CPP View: Displays and handles user interface controls for the RMS graph display.

Dialog popups:

DIALOGPATIENT. CPP DIALOGCALIBRATE. CCP DIALOGDATAAQ.CPP

Dialog for entering patient information. Dialog for entering calibration information.

Dialog that allows user to launch acquisitions of data and view acquisition parameters

(Scan rate, pre-amplifier gain, etc)

DIALOG SETTINGS, CPP SPLASHDIALOG, CPP

Dialog that allows editing of data acquisition and display parameters.

Popup display of software titles and spiffy back picture.

Data acquisition, filtering, and calculation: (763)

DAQHW.CPP READATOD.CPP FILTER.CPP

Interface to National Instruments software. Sets A/D board parameters and starts data acquisition Routines for calculating RMS values, converting A/D values to voltage, and signal conditioning

Filtering algorithms including high pass, low pass, and band pass with over-sampling

Reading and writing header information and data:

PATIENT.CPP CALIBRATE.CPP SETTING.CPP PAD.CPP

Read/Write patient information. Read/Write calibrate information. Read/Write settings information. Read/Write pad information. Read/Writa A/D scan.

Utilities: (165)

FILELIST.CPP

DATA.CPP

Routines for gathering unique descriptive file names and data files.

SORT.CPP

Routine for preforming heap sort.

COMPARE. CPP

Routine passed to sort function that handles comparison.

STDAFX.CPP

Includes and other preprocessor definitions.

Bitmaps, icons, resource files:

LEVELIA.BMP, LEVELIB.BMP,

LEVEL5B.BMP, LEVEL6.BMP, LEVEL7.BMP LEVEL8.BMP

LEVEL2.BMP, LEVEL3.BMP,

BITMAP1.BMP

Pictures of backs for use in RMS display.

LEVEL4.BMP. LEVEL5A, BMP,


Pad displayed in calibration dialog.


SPLASH1A.BMP


Splash screen.

TOOLBAR.BMP

Toolbar used at top of main window.















FIG. 39























FIG. 48




FIG. 49

